General Backpack Care & Cleaning Tips from WHOA!

- 1. Brush off loose dirt with a dry brush.
- 2. As needed, wipe out the inside with a damp sponge.
- 3. DO NOT soak in soapy water, as it may cause delamination!
- 4. <u>DO NOT</u> wash the pack in a washing machine or use any detergents to clean the pack!
- 5. Place pack on frame to air dry—air dry only. DO NOT put the pack in a dryer.
- 6. Always store in a cool, dry area.
- 7. If you have any questions about the pack, please call 803-323-2573.



Revised 6/11